


## Opening Control Dashboard (Utelogy user interface) for Main Menu



Double click Control Dashboard icon to open the Utelogy Dashboard to control the AV system in the room


## Main Menu



Select both projectors/or main projector only/or Smartboard only

Select to go to System Menu to Shutdown system/or select projectors.  
Red is off/Green is on.


## System Menu



## Volume Control and Select Computer as source

The screenshot shows the 'U-Control Dashboard - Room 1103 - Both Projectors' window. The interface includes the Pierce College logo and a bull icon, the text 'Room 1103', and 'Both Projectors'. It features three main control panels: 'Volume', 'Projector', and 'SmartBoard'. The 'Volume' panel has a vertical bar with up/down arrows and a 'Mute' button, with the volume level set at 75%. The 'Projector' panel has a dropdown menu with 'Computer' selected, and other options like 'Extended', 'Blu-ray', 'ScreenShare', 'HDMI', and 'VGA'. The 'SmartBoard' panel has a similar dropdown menu with 'Computer' selected. Blue callout boxes point to the 'Computer' selection in both the Projector and SmartBoard panels, with text: 'To display local computer in projector' and 'To display local computer in Smart board'. A larger blue callout box at the bottom left explains the volume controls: 'System Volume can be controlled by up/down buttons or dragging the bar to appropriate levels. Mute and Unmute is also available'. The Windows taskbar at the bottom shows the time as 10:47 on 8/16.


## Select Blu-ray as source



Single click on Blu-ray to select as a source

Double click Blu-ray bring out the control buttons

## Select Extended mode



Extended is used when you want to display laptop or computer in Extended Mode – extend to main projector

To Extend laptop or computer image to Smartboard

## Select HDMI

The screenshot shows the U-Control Dashboard for Room 1103. The interface includes a volume control section on the left, a central 'Projector' section, and a 'SmartBoard' section on the right. In the 'Projector' section, the 'HDMI' option is highlighted with a yellow bar. A blue callout box points to this selection with the text: 'Select HDMI to plug in external laptop using HDMI then select the output, projector or smartboard.'

U-Control Dashboard - Room 1103 - Both Projectors

**PIERCE COLLEGE** Room 1103 Both Projectors

Volume: 75 %

Projector:

- Extended
- Computer
- Blu-ray
- ScreenShare
- HDMI**
- VGA

SmartBoard:

- Extended
- Computer
- Blu-ray
- ScreenShare
- HDMI**
- VGA

10:48 8/16

## Select VGA

The screenshot shows the U-Control Dashboard for Room 1103. The interface is identical to the previous one, but in the 'Projector' section, the 'VGA' option is highlighted with a yellow bar. A blue callout box points to this selection with the text: 'Select VGA to plug in external laptop using VGA plug then select the output, projector or smart board.'

U-Control Dashboard - Room 1103 - Both Projectors

**PIERCE COLLEGE** Room 1103 Both Projectors

Volume: 75 %



Projector:


- Extended
- Computer
- Blu-ray
- ScreenShare
- HDMI
- VGA**

SmartBoard:

- Extended
- Computer
- Blu-ray
- ScreenShare
- HDMI
- VGA**

10:48 8/16







Room 1103

Smartboard

Volume

Volume



75 %

Display

SmartBoard

On

Off

Blank

Sources

Extended

Computer

Blu-ray

ScreenShare

HDMI


VGA



Extended has no control options available.



## Doc Camera (Elmo)



Open Image Mate Icon to open the Doc camera image and control. In order to show image of doc camera, it must be in the extended monitor first. Then you can select where to project (smart board or main projector).